Field Evaluation of the Next Generation of BG Sentinel® Trap, the Biogents Mosquitito®

John Smith, Eric Cope, and Jimmy Walsh



Objectives

- Evaluate the collection prowess of the Mosquitito in comparison with the BG Sentinel and MMX.
- 2. Determine if traps can effectively collect mosquitoes with lures in lieu of CO₂



Experimental Design

- Latin square
- Sept Oct, 2010
- PHEREC campus salt marsh
- 5 trap configurations
- 5 locations
- 3 repetitions
- 24 hrs from 8-8 a.m.



Treatments

- 1. Mosquitito + CO₂ + Sweetscent
- 2. Mosquitito + Sweetscent
- BG Sentinel + BG Lure
- 4. MMX + CO₂ + Octenol
- 5. MMX + Octenol



CO₂ Delivery - MMX

- 20 lb. compressed gas cylinders
- 15 psi regulator
- ¼" tubing, in-line filter, and .oo7 constrictor orifice
- 1.5 2.0# / 24 hrs.



CO₂ Delivery – Mosquitito

- Same tubing, regulator, filter and orifice
- Biogents diffuser nozzle
- 2.7 3.0# / 24 hrs.



BG Sentinel Trap






Biogents Mosquitito Trap





MMX Trap






Species Collected

Species	Total	%
An. crucians	6473	93.1
Ae. taeniorhynchus	340	4.9
An. atropos	56	0.8
Cx. quinquefasciatus	45	0.6
Ae. vexans	7	0.1
Ae. albopictus	7	0.1
Ae. atlanticus	5	0.1
Ps. columbiae	4	0.1
Ae. sollicitans	4	0.1
Ae. infirmatus	3	0.0
Ae. aegypti	3	0.0
Cx. salinarius	1	0.0
Ps. ciliata	1	0.0
Cx. restuans	1	0.0
Cx. erraticus	1	0.0
No catch	0	0.0
Grand Total	6951	100.0



Mean # Mosquitoes by Trap Configuration



Conclusions

- There was no significant difference in catch between the MMX and Mosquitito when equipped with CO₂ and lures
- 2. The Mosquitito used 50-100% more CO_2
- 3. Lures could not substitute for CO₂ without sacrificing catch numbers and species

